



Dimensional Drawing













General Specifications

Wire Resolution Typical AWG38
Penetration resolution Typical AWG34

Spatial resolution Vertical:1.0mm, horizontal:1.0mm

Penetration Typical 32mm
Resolution of organic matter 1-120mm
Grayscale and mixture resolution 1-40mm
Resolution of inorganic objects 0.2-14mm

Effective material resolution Meet the requirements of GB15208.1-2005

X-Ray dosage each inspection $\leq 3.0 \mu Sv (uGy)$ Boundary Leakage $\leq 1.0 \mu Sv /h(uGy/h)$

S/N ratio <60dB
Conveyor speed 0.2m/s
Conveyor max load 100kg
Power consumption 0.5KW

Safety performance requirements Meet the requirements of GB15208.1-2005

EMC requirements Meet the requirements of GB15208.1-2005
Electrical safety Meet the requirements of GB15208.1-2005
Environmental applicability Meet the requirements of GB15208.1-2005

Leakage current ≤ 5.0mA

Film Safety Guarantee ASA/ISO1600 Film

Weight 250kg

Operation temperature/Humidity 5 - 40 /0%-90%
Storage temperature/Humidity -20 -60 /10%-90%
Atmospheric pressure 86kPa-106kPa AC

Operation Power 220V(±10%-15%) 50±3Hz

Operation system LINUX

General Specifications

X ray generator 140KV, oil cooling, from bottom to top

Electric roller DGBL-76-380L


Computer Hard drive: 500G, Storage: 1G

Monnitor 21.5" LED screen, resolution: 1280*1024 pixels

Operation console Single screen console

Scanned images











www.nteksystems.com

 $sales@ntek systems.com \ / \ support@ntek systems.com$







Functional characteristics

Power-on self-test With the function of fault self-check, automatically judge the fault and prompt the fault code information in time.

1-64times enlargement continuity. Imag e processin g

With the function of Color/BW, negative, high/low penetration, organic/inorganic stripping,

general enhancement, and pseudo color, etc.

Image Recall 30 preceding images recallable.

Up to 10,00 images stored automatically. The number of images stored

The real-time curve can be used to detect whether the acquisition system and components work normally. Real-time curve

System time can be set Time setting

It can realize the manual deletion of the low and low energy detection board dead pixels, Probe setting

and display the deleted dead pixels in the display area.

There are two source and analog source control modes, the source parameters of the digital source can be set. Ray source setting

The alarm function can be activated and deactivated, and the alarm type of the alarm box, Alarm system

sound and light alarm can be selected, and the sensitivity, minimum absorption rate,

maximum absorption rate, and alarm duration can be set.

It can realize whether the components such as the entrance and exit light barrier, side panel switch, emergency Troubleshooting

stop switch and light source are normal, and display the standard value and current value of the detection voltage

The drum running control direction and the image display moving direction can be set. Image setting

It can realize software registration function and has serial number, registration code, Software registration

registration status and system time information display.

User login Log in by entering different user name and passwords, only when logging in can you make other settings.

User management You can add, delete, edit the user name and password, set the user level to restore the deleted user.

Authority management Different default permissions can be set according to user level.

language settings The system language can be set to switch between Chinese and English.

Log management User operations can be monitored to query user actions.

About The version and device number can be displayed.

TIP report The report can be generated by the tip operation after the tip insertion function is turned on, and the

content of the report: user name, number of tip insertions, number of tags, false positive rate,

probability of detection, probability of false positives.

It can query, open, and export the checked image.

Tip management It can be set to enable and disable the insertion of dangerous goods, and can set the identification time,

Prompt time, insertion frequency, proportion of single items inserted into dangerous goods, add tip files

It can set log level, save the file time, whether to open the training function and setting the smart roller.

It can select the exported data, pictures, and backup directory, select and adjust the motor type, detector type, whether to enable the debug mode, model, and gain, enter the corresponding IP address on network connection to realize sharing function, and have corresponding software to achieve system upgrade.

Display system working hours, the total working hours of the ray source, the total number of system baggage and packages, and the total number of baggage packages this time, and clear the above data.

and delete files.

Document management

Function setting

Data setting

Compliance

System parameter setting

*ISO19001; SO14001; ISO27001; OHSMS18001; CE, ROHS, FCC, REACH, USA, FDA

International *Health Inspection Report

*Computer Software Copyright Registration Certificate National (China)

*Software Product Registration Certificate

*Radiation Safety Certificate from Ministry of Public Security

*Quality Certification from Safety and Police Electronic Products Quality Inspection Center

*Design pantent certification





